

TICTACFLASH

This is a small guideline of how-to build a colorful tictacflash for your LOMO LC-A. Attention this is for advanced Lomographers and electronic friends only. Be careful and always be aware of the high voltages of a flashgun!

Step 1: Buy a onetimeuse camera and some tictacs (we will use the box(es) only, you may devour the tictacs as fee for your work ;-).



Step 2: Disassemble the cam and extract the flash PCB.



Step 3: If necessary shorten the PCB, re-arrange some components and try to fit into a small tictac box.



Step 4: Solder the wires to a self-made flash contact (metal washer, plastic washer and metal screw).



Step 5: Use your favourite color tic tac box and enjoy your cheap and exclusive LOMO tictacflash.



Happy shooting! :-)



Of course all hints are given without any warranty or guarantee. So it's on your own risk. But no risk no fun ;-)